

## HEAT ENGINES

Link to: [physicspages home page](#).

To leave a comment or report an error, please use the auxiliary blog.

Reference: Daniel V. Schroeder, *An Introduction to Thermal Physics*, (Addison-Wesley, 2000) - Problem 4.1.

A heat engine is a system that absorbs heat and converts part of that heat into work, which can be extracted to perform other tasks. In practice, all heat engines absorb a certain amount of heat and can convert only part of that heat into work, with the remainder being expelled back into the environment. An idealized heat engine absorbs an amount of heat  $Q_h$  from a thermal reservoir at constant temperature  $T_h$ , converts an amount  $W$  of this heat into work, and expels the remainder  $Q_c$  into another thermal reservoir at a constant temperature  $T_c$ . The efficiency  $e$  of the heat engine is the fraction of  $Q_h$  that is converted into work, so

$$(1) \quad e = \frac{W}{Q_h} = \frac{Q_h - Q_c}{Q_h} = 1 - \frac{Q_c}{Q_h}$$

Since the absorbed heat  $Q_h$  is equal to the sum of the work done and the heat expelled, the heat engine itself returns back to its original state at the end of the process. By driving the engine in a cycle of such processes, a continuously operating engine can be obtained.

At this point, it might seem that by merely arranging for no heat to be expelled so that  $Q_c = 0$ , we could develop a perfectly efficient engine that converts all its input heat into work. However, the second law of thermodynamics throws a spanner into the works, since it requires that entropy increases in any process that involves heat transfer. From the macroscopic definition of entropy, the amount of entropy absorbed from the hot reservoir is

$$(2) \quad S_h = -\frac{Q_h}{T_h}$$

(I've written it with a minus sign, since the entropy of the hot reservoir decreases.) The amount expelled into the cold reservoir is

$$(3) \quad S_c = \frac{Q_c}{T_c}$$

The overall change in entropy must be positive, so

$$(4) \quad S_h + S_c = \frac{Q_c}{T_c} - \frac{Q_h}{T_h} > 0$$

In other words

$$(5) \quad \frac{Q_c}{Q_h} > \frac{T_c}{T_h}$$

Thus the only way  $Q_c$  can be zero (to get 100% efficiency) is if the cold reservoir is at absolute zero. In fact, the best we can do is to get an efficiency of

$$(6) \quad e \leq 1 - \frac{T_c}{T_h}$$

As an example, suppose we look again at the monatomic ideal gas that is driven around a rectangular cycle on a  $PV$  diagram. To review, the system is as follows. The path is a rectangle starting at  $P_1$  and  $V_1$ . On side A, the pressure is increased to  $P_2$  while the volume is held constant. Then on side B, the volume is increased to  $V_2$  while the pressure is constant at  $P_2$ . On side C, the pressure is decreased back to  $P_1$  with the volume constant at  $V_2$ . Finally, on side D, the volume is decreased back to  $V_1$  with the pressure constant at  $P_1$ . From the table in the earlier post, we see that heat is added to the gas along sides A and B, and removed from the gas along sides C and D. The net work done by the gas is given by

$$(7) \quad W = Q_A + Q_B + Q_C + Q_D$$

where  $Q_C < 0$  and  $Q_D < 0$  to indicate that heat is leaving the gas. We can calculate the efficiency of this cycle if it is used as a heat engine:

$$(8) \quad e = 1 - \frac{Q_{\text{expelled}}}{Q_{\text{absorbed}}}$$

$$(9) \quad = 1 - \frac{-Q_C - Q_D}{Q_A + Q_B}$$

For the particular case  $P_2 = 2P_1$  and  $V_2 = 3V_1$  given in the problem, and reading the formulas for the heats off the table in the previous post, we get

$$(10) \quad Q_A = \frac{5}{2}V_1(P_2 - P_1) = 2.5P_1V_1$$

$$(11) \quad Q_B = \frac{7}{2}P_2(V_2 - V_1) = 14P_1V_1$$

$$(12) \quad -Q_C = \frac{5}{2}V_2(P_2 - P_1) = 7.5P_1V_1$$

$$(13) \quad -Q_D = \frac{7}{2}P_1(V_2 - V_1) = 7P_1V_1$$

[The sign conventions can be a bit confusing, since Schroeder refers to all heat and work quantities as positive, whereas in the earlier chapters a distinction was made between heat absorbed by the gas and emitted by the gas.]

The efficiency is therefore

$$(14) \quad e = 1 - \frac{14.5}{16.5} = 0.12$$

This isn't a very efficient cycle for a heat engine.

In the course of the cycle, the gas varies between a low temperature of  $T_c = P_1V_1/Nk$  and a high temperature of  $T_h = P_2V_2/Nk = 6T_c$ . Thus the theoretical maximum efficiency is

$$(15) \quad e_{max} = 1 - \frac{1}{6} = 0.83$$

#### PINGBACKS

Pingback: Power plants as heat engines

Pingback: Ocean water as a heat engine

Pingback: Carnot cycle

Pingback: Refrigerators

Pingback: Super-efficient heat engines and refrigerators

Pingback: Internal combustion engine; the Otto cycle