

AIR CONDITIONERS

Link to: [physicspages home page](#).

To leave a comment or report an error, please use the auxiliary blog.

Reference: Daniel V. Schroeder, *An Introduction to Thermal Physics*, (Addison-Wesley, 2000) - Problem 4.13.

An air conditioner is an example of a refrigerator in which the cold reservoir is the room to be cooled and the hot reservoir is the outside atmosphere. On a hot day, the rate at which heat leaks into an air conditioned room from the outside is roughly proportional to the temperature difference $T_h - T_c$ between the outside and inside. In that case, the work done to remove an amount Q_c of heat in time Δt is

$$(0.1) \quad W = Q_h - Q_c = Q_h - K(T_h - T_c)$$

where Q_h is the heat expelled to the outside and K is a constant.

In an ideal refrigerator (e.g. one working on a reversed Carnot cycle) the entropy gained in absorbing Q_c is equal to the entropy lost in expelling Q_h , so

$$(0.2) \quad \frac{Q_c}{T_c} = \frac{Q_h}{T_h}$$

$$(0.3) \quad Q_h = \frac{T_h}{T_c} Q_c$$

$$(0.4) \quad = K \frac{T_h}{T_c} (T_h - T_c)$$

The work required to maintain a temperature of T_c is therefore

$$(0.5) \quad W = K \frac{T_h}{T_c} (T_h - T_c) - K(T_h - T_c)$$

$$(0.6) \quad = \frac{K}{T_c} (T_h - T_c)^2$$

Thus lowering the inside temperature by a small amount can have a large effect on the work required to maintain this temperature, and thus on the cost of running the air conditioner. For example, suppose the outside temperature is $30^\circ \text{C} = 303 \text{K}$ and the inside temperature is $22^\circ \text{C} = 295 \text{K}$. If we wish to lower the inside temperature by only one degree, the extra work required is

$$(0.7) \quad \frac{W_{294}}{W_{295}} = \frac{295^2}{294^2} = 1.27$$

We need to use 27% more power to achieve a single degree more cooling. This is one reason why it is much more economical to bear with a slightly higher indoor temperature on a hot day.

PINGBACKS

Pingback: Heat pumps